



Maxplus Concealed Waterstop Installation Instructions

1. Prepare the substrate for Waterstop adhesion.




- Ensure the area is clean and free of debris. This is important as it allows the adhesive and Waterstop to properly adhere to the substrate
- Install a substrate primer to the substrate in accordance with brand manufacturer guidelines.

2. Install Self Adhesive Bandage to the Shower Enclosure



- Ensure the area is correctly prepared in accordance with manufacturer guidelines and install the self adhesive bandage to the shower enclosure.
- Ensure to remove as many bubbles and ridges in the bandage as possible to allow the Waterstop to sit flush against the bandage. This will ensure correct adhesion.

3. Install the Waterstop




- Measure the area where the Waterstop is to be installed, and cut to fit. Ensure to mitre the external corner (if required).

- Apply two even beads of solvent free construction adhesive to the base of the Waterstop and install onto the substrate. Make sure to firmly push the Waterstop down to allow the adhesive to bond to the substrate.

- Once the adhesive has dried, use the same solvent free construction adhesive to the external and internal corners, and termination points to ensure that the Waterstop is sealed in place.


4. Install Self Adhesive Bandage along the Waterstop



- Apply Self Adhesive Bandage to the length of the Waterstop to seal it in place. Then apply a saddle flashing to the termination point of the Waterstop to the wall.


- Please ensure that the Self Adhesive bandage is installed up and over the top of the Waterstop to allow for maximum coverage.

5. Apply the Waterproofing Membrane



- Install Waterproofing membrane to the shower enclosure and applicable surrounding areas.
- Ensure that the Waterproofing Membrane is installed up and over the top of the Waterstop to allow for maximum coverage.
- Please pay careful attention to correct dry film thickness and internal corner details.
- Ensure Membrane is fully cured as per manufacturers instructions before proceeding.


6. Install Tiles



- Install adhesive and tiles over the Waterproofing membrane. The Waterstop should sit just below the top of the tile.
- Run a bead of silicone (to match the grout colour) along the top of the Waterstop.


Maxplus Tile Finish Waterstop Installation Instructions

1. Prepare the substrate for Waterstop adhesion.



- Ensure the area is clean and free of debris. This is important as it allows the adhesive and Waterstop to properly adhere to the substrate
- Install a substrate primer to the substrate in accordance with brand manufacturer guidelines.


2. Install the Waterstop



- Measure the area where the Waterstop is to be installed, and cut to fit. Ensure to mitre the external corner (if required).
- Apply two even beads of solvent free construction adhesive to the base of the Waterstop and install onto the substrate. Make sure to firmly push the Waterstop down to allow the adhesive to bond to the substrate.

- Once the adhesive has dried, use the same solvent free construction adhesive to the external and internal corners, and termination points to ensure that the Waterstop is sealed in place.


4. Install Self Adhesive Bandage along the Waterstop



- Apply Self Adhesive Bandage to the length of the Waterstop to seal it in place.

- Apply Self Adhesive Bandage as a saddle flashing to the junction between the doorframe and the Waterstop.

5. Apply the Waterproofing Membrane




- Install Waterproofing membrane to the shower enclosure and applicable surrounding areas. Ensure that the Waterproofing Membrane is installed up the wall as per correct practice.

- Ensure that the Waterproofing Membrane is installed up and over the top of the Waterstop to allow for maximum coverage.

- Please pay careful attention to correct dry film thickness and internal corner details.
- Ensure Membrane is fully cured as per manufacturers instructions before proceeding.

6. Install Tiles



- Install adhesive and tiles over the Waterproofing membrane.
- The Waterstop should lip slightly over the tiles like an L-Profile trim.


Important Information

To ensure that the Maxplus Waterstops function correctly, all steps must be followed precisely and according to manufacturers instructions.


All parts of the shower enclosure including the waste needs to be detailed correctly in accordance with AS:3740 to ensure that the Maxplus Waterstop will perform correctly.

These waterstops are designed to be used in conjunction with any waterproofing system, as long as the membrane is installed as per the manufacturers instructions. This system must be suitable for adhering to aluminium.

Tilemax will not be held accountable or liable for any issues resulting from incorrect installation of the Maxplus Waterstop, or Adhesive/Waterproofing Membrane systems.



* Installed per membrane suppliers specifications. Not all membrane systems require the use of a self adhesive bandage, we recommend checking the brand specifications prior to installation.



* Installed per membrane suppliers specifications. Not all membrane systems require the use of a self adhesive bandage, we recommend checking the brand specifications prior to installation.